

### HIKVISION Fever Screening Thermal Camera Installation & Configuration Guide









**Turret:DS-2TD1217B** 

Installation-Tripod quick temporary deployment

**Temperature measurement range**: 30-45°C

Working temperature: 10-35°C

Accuracy: ±0.5°C **Resolution**:  $160 \times 120$ 



**Tripod Adapter For** Turret




Tripod Adapter for Bullet





A. Tripod connector fixed on the adapter







B. Fix the adapter on the camera



C. Install the camera on the tripod




D. Installation complete

Installation Parameter Recommended					
Model	Distance (between human&camera)				
DS-2TD1217B-3/PA	0.9.1 5 mg				
DS-2TD2617B-3/PA	0.8-1.5m				
DS-2TD1217B-6/PA	1 5 2 00				
DS-2TD2617B-6/PA	1.5-3m				

Model	Height	Elevation angle	
DS-2TD1217B-3/PA	1.5m	≤20°	
DS-2TD2617B-3/PA			
DS-2TD1217B-6/PA			
DS-2TD2617B-6/PA			

## Configuration

### Select Body Thermography as VCA Resource Type. VISION Live View **Picture** Configuration Playback



VISION Live View Playback Configuration

Live View Parameters


and save the following settings:

following settings:

	System	Protocol	TCP	○ UDP	○ MULTICAST ○ HTTP
0	Network	Play Performance	O Shortest Delay	<ul><li>Balanced</li></ul>	○ Fluent
Q.	Video/Audio	Rules	<ul><li>Enable</li></ul>	○ Disable	
**	Image	Auto Start Live View	○ Yes	No	
≝	Event	Image Format	JPEG	○ BMP	
	Storage	Display Rules Info. on Ca	Yes	○ No	
<b>B</b>	Body Thermometry	Display Temperature Info	.   Yes	○ No	
		Display Temperature Info	Yes	○ No	
3. Go to Body Thermography Basic Settings. Configure					

VISION Live View Playback Picture Configuration Linkage Method


Channel No.



**Advice** 

**Body Thermometry Configuration** 

4. Configure Camera 01 (Optical) Settings.





Suggest uncheck Upload Captured Face Image and Display Face **Temperature Position** if its not a must. Set Alarm Temp. and Pre-alarm Temp. Press **Draw Area** to adjust face detection region.

Check Enable Face Detection and Display Temperature.

Click Max. Pupil Distance and Min. Pupil Distance to draw width filter frame, Max and Min distance refer to camera

detection distance. -18-2020 Wed 20:52:58





# Here's some advice:

The environment would easily influence the performance of thermal camera. Therefore, it is required to be used in a stable indoor environment without wind, and the ambient temperature should be consistent.

- 1. Set up a one-way screening zone, and ensure that camera can clearly see the face of person whose body temperature is being measured. 2. Avoid backgrounds that are too crowded or bright.
- 3. 30 minutes after turn on the camera, then go body temperature measurement, because the camera itself needs to be steady first.
- 4. If there is a large gap between indoor and outdoor temperature, it is highly suggested to wait more than 5 minutes then measure body temperature of whom just got in.
- 5. Follow the guidance of required temperature measurement distance.