Always Safer



SMOKE DETECTOR











SD-10B8



INSTALLATION AND OPERATION:

INSTALLATION

Smoke detector SD-10B8 should be installed in places where there exists possibility of potential fire threat. While choosing the place of installation the user should make sure that the alarm sound will be heard from the whole building. The device should be installed on ceiling.

- 1. Separate mounting frame (fig. 1 pos. 1) from the device body (fig. 1 pos. 2), rotating it counter-clockwise.
- 2. Put the 9V battery, 6LR61 type (fig. 2 pos. 1).
- 3. Test the device by pressing the button at the front (fig. 3 pos. 1) until the sounds from the device speaker can be heard. The sound in the speaker confirms that the device works properly.
- 4. Install the device on the ceiling. At first the mounting frame should be fixed to. the ceiling using screws and screw anchors (included in the set). Two holes in the mounting frame should be used for installation. Next step is attaching the device body to the frame by inserting two characteristic hooks of the frame (fig. 4 pos. 1) into two channels on the device body (fig. 4 pos. 2). Finally the body should be rotated clockwise to be fixed

NOTES:

- You must not replace any components of the device except batteries. In case of any problems you should contact the vendor's service.
- The device must not be installed in places with high humidity level or in dusty space.
- The device should be installed in places that are already finished and painted.
- The device should be installed at least 1.5 m from the air conditioning.
- The device should be tested at least once a month.
- Single repeating sounds appearing during standby mode at intervals of 30-40 seconds are a low battery symptom. This means that the battery should be immediately replaced.







